

# Dura-Whelp Box Assembly Instructions



1. Unfold and lay out the floor with the Velcro tabs facing up.



2. Unfold the walls and place them on the floor.



3. Fold up sides of floor and press both sides of the Velcro together.



4. While pulling back on the walls without the holes in them, insert the rails without tabs through the holes on the wall and line up the matching shapes. When aligned, release the wall and push Velcro together to secure rails to the wall.



5. Place the two rails with tab ends on top of the already installed rails. Velcro should be facing the walls. Slide the tab rails toward the walls so that the Velcro secures them into place. Align the pre-drilled holes in the tabs with the pre-drilled holes in the rails and screw together using the screws provided.



6. Your Dura-Whelp whelping box is now completely assembled. The door slides up and down.

## Important:

- To dismantle, reverse these instructions.
- Save reusable shipping carton for storing your Dura-Whelp.
- Replacement screws can be purchased at any local hardware store - #6 pan-head sheet metal screw.

# Dura-Whelp Whelping Box Cleaning and Maintenance

## Instructions

The Dura-Whelp may be cleaned with Bleach, Parvocides, or other detergents or disinfectants.

If Newspaper print stains the plastic, it may be removed with Clorox Soft Scrub (for counter tops.)

Warranty Information – We guarantee the Dura-Whelp® box and Weaning Pen to be usable for a period of 3 years from the original date of purchase. We will replace or repair free-of-charge any of our guaranteed items which is unusable due to manufacturing defects. Warranty does not apply to repairs needed because of chewing, accident, or negligence.

Dura-Whelp

PO Box 8, Clifton, ID 83228

(208) 747-3605

[info@durawhelp.com](mailto:info@durawhelp.com)

